



Uputstvo za montažu




Izbušiti rupu




Očistiti rupu



Postaviti anker uz
pomoć čekića ili
alata za postav-
ljanje



Ukucati anker



Ostvariti obrtni
moment